


Steps on how to charge and replace the battery on a Workstation on Wheels (WoW).

 **To avoid losing power to devices, ensure a charged battery is installed or the unit is plugged into AC power.**

## Charge Battery

To **charge** the battery:


1. Plug power module into wall outlet
2. Ensure display is on. If the display is off, press the button to turn it on as the display must be on for battery to charge



## Replace Battery

To **replace** the battery:

1. Bring the WoW to the 4-bay battery charger  
or  
Retrieve a fully charged battery from the 4-bay battery charger before removing the current battery from WoW
2. Squeeze the battery handle and pull the battery out to remove it from the WoW




**Once the battery is removed, the power module will continue to supply power to the devices for up to 2 minutes. Ensure the replacement battery is ready to avoid disruption.**



3. Place fully charged battery onto the WoW power module
4. Place old/dead battery from WoW on 4-bay battery charger

 **Ensure the battery is seated correctly** - do not drop it onto the power module.

- When properly connected, a light on the battery will turn on for about 3 seconds
- The display will show the battery power level and estimated time remaining
- **If the battery is not properly connected, do not force it into place. Remove the battery and try again**



### View Battery Status

<p>Battery fully charged</p>	
<p>Battery plugged in and charging (lightning bolt indicates charging) and battery shows fully charged</p>	
<p>Battery is dead/missing and battery replacement timer up to 2 minutes is started. Battery needs to be replaced before timer gets to zero or WoW will turn off abruptly</p>	